




	<b>Part No. 023-111</b>
	<b>A = 6.5</b> <b>B = 25.25</b> <b>C = 16</b> <b>D = 24.5</b>

	<b>Part No. MR-24-02</b>
	<b>A = 20</b> <b>B = 25</b> <b>C = 16</b> <b>D = 24</b>

	<b>Part No. 4003PRN</b>
	<b>A = 6</b> <b>B = 25</b> <b>C = 15</b> <b>D = 25</b>


	<b>Part No. 10974</b>
	<b>A = 4.6</b> <b>B = 25.3</b> <b>C = 18.5</b> <b>D = 26.7</b>


	<b>Part No. 013079A</b>
	<b>A = 5.8</b> <b>B = 30</b> <b>C = 20.5</b> <b>D = 30</b>


	<b>Part No. 0131079</b>
	<b>A = 5.8</b> <b>B = 30</b> <b>C = 20.5</b> <b>D = 30</b>


# AMEGA ENGINEERING SUCKER LIST


## RING & HORSESHOE SUCKERS





	<b>Part No. AME-R34</b>
	<b>A = 8</b> <b>B = 32</b> <b>C = 15.5</b> <b>D = 32.5</b>

	<b>Part No. AME-33</b>
	<b>A = 6.5</b> <b>B = 30</b> <b>C = 21</b> <b>D = 33.5</b>

	<b>Part No. B8095111JG</b>
	<b>A = 6</b> <b>B = 30</b> <b>C = 21</b> <b>D = 33.5</b>

	<b>Part No. ROBIMAT</b>
	<b>A = 5</b> <b>B = 46.3</b> <b>C = 13</b> <b>D = 46.3</b>

	<b>Part No. 149509</b>
	<b>A = 11.5</b> <b>B = 7.5 (x3)</b> <b>C = 3.8 (x3)</b> <b>D = 32.5 x 8.2</b>

	<b>Part No. PSA9626201605</b>
	<b>A = 4.8</b> <b>B = 4</b> <b>C = 2</b> <b>D = 13 x 4</b>

# AMEGA ENGINEERING SUCKER LIST

## RING & HORSESHOE SUCKERS